# **Warranty Information**



Chrome, Brushed Nickel, Brushed Gold, Matte Black

PASGO faucet warrants the original purchase (must have prove of purchase) that such product is free from defect in materials or workmanship for as long as the original consumer purchaser owns their home from the date of purchase. This warranty is limited to but not including labor charges incurred in/or damages sustained during installation, repair or replacement, nor incidental or consequential damages. This warranty does not cover items which are received secondary finishing or have been altered or modified after purchase, or for defects raised by physical abuse to or misuse of the product. This warranty gives the original purchaser of a PASGO faucet specific legal rights which may vary from state to state or from province to province. In some states or provinces the exclusion or limitation incidental or consequential damages is not allowed, for those exclusions may not apply to you

BR7036 009 BR1016T BR1014T BR7037 CZ1010S **BR017** BR1018 19920\* 19930\* 19939\* 19940\* 19920A\* 19930A\* 19939A\* 19940A\* 19949A\* 9799 9758 BC004 BC011 BC011A BC005

Thank you for your purchase

### **Installation Guidelines**


Pipe Flushing


- 1. Before installation: Please leave the water pipe clean without impurities nd sludge to prevent from blocking.
- 2. Do Not disassemble the Faucet valve. It has been tested by the manufactory.
- 3. During installation: Please install a filter in the inlet pipe in order to check whether the filter is blocked or not.
- 4. After installation: Please double check and be sure that all the connections are well connected, no leakage and no crackage unitlyou seal the wall.
- 5. Make sure to empty the water pipe and faucet if room temperature is below 0°C (32°F), or else if may cause freeze.
- 6. Please install floor drain in the place where this product is used!

## Common Installation tools you may need:




### **Installation Steps**







#### **Faucet valve part Installation Steps**










pipes.



pipes.


2. Fix the screws and Faucet valve on the wall.

2. Fix the screws and Faucet valve on the wall.

pipes.

2. Fix the screws and Faucet valve on the wall.


2. Fix the screws and Faucet valve on the wall.




. Take out the protector, bag and screws from Faucet valve.


Faucet valve.

3. Take out the protector from 3. Take out the protector, bag and screws from Faucet valve.



3. Take out the protector from Faucet valve.







panel and screw back.

**BR1016T** 

1. Preset the position of

2. Dismantle the screws

out the base.

by Allen Key and take

Shower panel and

make a mark.

**Shower Outlet** 

**BR016** 

Floor

base; press the buttom 2. Open the lid of the

1. Preset the position

of sliding bar and

make a mark.

2. Open the lid of the

of the holder and insert

**BR017** 

Floor

1. Preset the position

of sliding bar and


base: press the buttom


of the holder and insert

it in the tube.

Press


make a mark.





tube and the other side o

the base.








into the Shower bar, align the mounting holes of Shower bar with the water outlet connector and the fixed connector and install. screw them up with Allen key; Install the tube into the shower bar, adjust the direction of the water outlet and tighten the screw with a hexagonal key.

the base.





for open, water flow either comes out from hand held or spout: The greater the angle, the higher the water temperature; Close

while turns back to

. Turn left of the handle

comes from the shower

head: The greater the

angle, the higher the


Close while turns back

water temperature;


to original position.


for open, water flow

original position.



Cold





9758

for open; The greater

the angle, the higher


the water temperature

Close while turns back

to original position.

2. Water flow either comes

out from hand held or



. Turn right of the handle

for open; The greater

the angle, the higher

the water temperature;

Close while turns back

to original position.

to switch.

. Turn right of the handle

for open; The greater

the angle, the higher

the water temperature;

Close while turns back

to original position.

2. The upward indicator

shows the status of

1. Turn right of the handle

for open; The greater

the angle, the higher

the water temperature

Close while turns back

to original position.